



ADAPTERS AND CONNECTORS

[www.adaconn.com](http://www.adaconn.com)

(215) 643-1900

FAX (215) 643-4017

MODULAR VALVES AND FITTINGS

[www.inserta.com](http://www.inserta.com)

(215) 643-0192

538 TOWNSHIP LINE ROAD • BLUE BELL, PA 19422-2798

## **CHECK VALVE CRACKING PRESSURE**

Cracking pressures listed are nominal. Typical cracking pressure is expected to be within 15% of the nominal value.

Cracking pressure is defined as the pressure across the valve whereby individual drops coalesce into a stream.